

**A & M HARDWARE INC
2705 MOUNT JOY ROAD
MANHEIM, PA 17545
888-647-0200**

www.AandMhardware.com

ADA Vanity Mounting Instructions

Mount ADA Brackets to the wall securing it to meet local building code required loading requirements for the vanity front edge.

Note: Double studs or metal mounting plates are recommended for a stronger installation.

Note: Use ADA bowls when using the ADA Brackets

Install Spring Clips to the back of the Face Board

Spring Clips should be installed with 12 ¾ inches between the top of the top bracket and the top of the bottom bracket.

There will be some side to side allowance on the clip installation

Be sure to allow 1" clearance between the top of your Face Board and the bottom of the top portion of the bracket to allow the Face Board to slide up for removal